

60"/72" Vanity Centre Support Leg Adjustment

A new support leg has been designed to provide extra support to the middle of the 60" and 72" vanities, preventing them from sagging under the weight of the countertop. Tools for adjusting the support leg are provided. These items are:

- An Allen key
- A White cap (covers the support leg once installed)

STEP BY STEP INSTRUCTIONS

Step 1 – Locate and access the pre-installed support leg

For your convenience, the support leg has already been partially installed (PIC. 1). It is located a few centimeters from the back edge of the bottom panel of the vanity, in the centre. If you are working with a double sink vanity, you will need to remove your drawers in order to access the support leg. See the Door and Drawer Adjustment Instructions (pg. 4.5) for instructions on how to remove the drawers.

Step 2 – Adjust the support leg so that the bottom of the support leg is flush with your floor

Use the included Allen key to adjust the support leg so that the bottom (the flat section) of the support leg meets your floor. To do this, insert the short end of the Allen key into the top of the support leg (PIC. 2).

Slowly rotate the Allen key clockwise. Notice the support leg dropping down through the pre-drilled hole. When you begin to feel resistance, the flat section of the support leg is flush with your floor. Remove the Allen key.

Step 3 – Test the vanity for its flatness

Use a laser or bubble level to ensure the support leg has not been over-adjusted or under-adjusted, which will cause your countertop and backsplash to sit unevenly on your vanity.

Place your levelling tool on top of your countertop. If the level reads as flat, then your support leg has been adjusted properly. You can use the included backsplash and the level itself to see if the support leg needs to be adjusted clockwise or counter-clockwise.

If the backsplash has a large gap or appears raised in the middle, but flush with your countertop on its ends, the support leg has been under-adjusted. Continue to adjust the support leg by rotating the Allen key clockwise until the backsplash is flush across the whole countertop.

If the backsplash is flush with the countertop in the middle but has large gaps or appears raised on its ends, the support leg has been over-adjusted. Re-adjust the support leg by rotating the Allen key counter-clockwise until your backsplash is flush across the whole countertop.

With the support leg properly adjusted, your backsplash will be flush with the countertop (PIC. 3) Note: The support leg may require additional adjustment as the vanity settles under the weight of the countertop. Keep your Allen key for future use.

Step 4 – Install the white cap to conceal the support leg.

The white cap that was included with the Allen key is used to conceal the support leg. Place the cap over the hole with the flat side facing up then, using your thumb, press the white cap into the hole.



PIC. 1



PIC. 2



PIC. 3

Distributor of:

STONEWOOD
BATH CABINETRY

Yorkville
VANITIES

316 Bayview Dr., Barrie, ON L4N 8X9
P: 705.719.4870 | F: 1.866.376.7154
E: orders@rocksolidsupply.com

© 2018 Rock Solid Supply
Revised 21/08/2018
Page 1 of 1